Warning	Description
! ! (yellow)	The camera is approaching the maximum temperature al-
CAMERA IS APPROACHING	lowed when STANDARD is selected for AUTO POWER
STANDARD	OFF TEMP. and will shortly turn off automatically. Turn the
TEMPERATURE LIMIT	camera off and wait for it to cool.
! ! (yellow)	The camera has reached the maximum temperature al-
HIGH TEMPERATURE	lowed when STANDARD is selected for AUTO POWER
LIMIT REACHED	OFF TEMP. and is about to turn off automatically. Turn the
SHUTTING DOWN	camera off and wait for it to cool.
! (yellow) CAMERA IS APPROACHING	The camera is approaching the maximum temperature
	allowed when HIGH is selected for AUTO POWER OFF
	TEMP. and will shortly turn off automatically. Remaining
HIGH TEMPER-	in contact with the camera could result in low-temperature
ATURE LIMIT.DO NOT	burns; mount the camera on a tripod or take other steps to
HOLD CAMERA FOR	avoid prolonged contact with the camera. The camera will
LONG PERIODS OF TIME	shortly turn off automatically. Turn the camera off and wait
LONG! ENIODS OF TIME	for it to cool. Mottling may increase in pictures taken when
	this warning is displayed.
	The camera has reached the maximum temperature al-
!! (red)	lowed when HIGH is selected for AUTO POWER OFF
HIGH TEMPERATURE	TEMP. and is about to turn off automatically to prevent
LIMIT REACHED	low-temperature burns. Turn the camera off and wait for it
SHUTTING DOWN	to cool. Mottling may increase in pictures taken when this
	warning is displayed.