Tethered Photography via Wireless LAN

Connect to a wireless LAN to use a computer on the network for tethered photography.

- 1 Select CREATE/EDIT CONNECTION SETTING > CREATE USING WIZARD in the network/USB setting menu and choose TETHERED SHOOTING (19 313).
- Select CREATE NEW.
 - Choose **SELECT FROM LIST** to select from a list of existing connection setting profiles.



3 Press **MENU/OK** when prompted.



4 Select WIRELESS LAN.



5 Select CREATE NEW to create a new communication setting profile.



