## **EDIT FILE NAME**

Change the file name prefix. sRGB images use a four-letter prefix (default "DSCF"), Adobe RGB images a three-letter prefix ("DSF") preceded by an underscore.

Option	Default prefix	Sample file name
sRGB	DSCF	ABCD0001
AdobeRGB	_DSF	_ABC0001

## CARD SLOT SETTING

Choose the role played by the card in the second slot.

Option	Description	
SEQUENTIAL	The card in the second slot is used only when the card in the	
	first slot is full.	
BACKUP	Each picture is recorded twice, once to each card.	
SEPARATE	RAW pictures will be saved to the card in the first slot and	
	JPEG or HEIF pictures to the card in the second slot. This op-	
	tion only takes effect when SUPER FINE+RAW, FINE+RAW	
	or NORMAL+RAW is selected for MIMAGE QUALITY	
	SETTING > IMAGE QUALITY.	

## SELECT SLOT( SEQUENTIAL)

Choose the card that is recorded to first when **SEQUENTIAL** is selected for **CARD SLOT SETTING**.

Options			
SLOT 1	SLOT 2		