| Problem | Solution |
|-----------------------|--|
| Pictures are blurred. | The lens is dirty: Clean the lens. |
| | • The lens is blocked: Keep objects away from the lens |
| | (章 45). |
| | • !AF is displayed during shooting and the focus frame is dis- |
| | played in red: Check focus before shooting (🕮 46). |
| Pictures are mottled. | • Shutter speed is slow and the ambient temperature is high: This |
| | is normal and does not indicate a malfunction.* Use pixel |
| | mapping (🗎 117). |
| | * X-rays, cosmic rays, and other forms of radiation interacting with the image sensor may cause bright spots of various colors such as white, red, and blue. Pixel mapping helps reduce the occurrence of such bright spots. |
| | • The camera has been used continuously at high temperatures: |
| | Turn the camera off and wait for it to cool down (\$\equiv 38\$, 316). |
| | • A temperature warning is displayed: Turn the camera off and wait for it to cool down (■ 38, 316). |