4K HDMI STANDBY QUALITY

Choose whether output to connected HDMI devices switches from 4K to Full HD during standby.

Option	Description						
4K	Output to HDMI devices continues at 4K during standby.						
HIIIDH	Output to HDMI devices switches to Full HD during standby, reducing the drain on the battery.						

HDMI REC CONTROL

Choose whether the camera sends movie start and stop signals to the HDMI device when the shutter button is pressed to start and stop movie recording.

Options					
ON	OFF				

ZEBRA SETTING

Highlights that may be overexposed are shown by zebra stripes in the movie mode display.

Option	Description						
ZEBRA RIGHT	//// Right-slanting stripes.						
ZEBRA LEFT	∭ Left-slanting stripes.						
OFF	Stripes off.						

ZEBRA LEVEL

Choose the brightness threshold for the zebra stripe display.

Options											
50	55	60	65	70	75	80	85	90	95	100	