USB POWER SUPPLY SETTING

Choose whether power is supplied to the camera when it is connected to a computer or other device via a USB cable.

Option	Description
	The camera draws power from the connected device, reducing
	the drain on the camera battery.
OFF	The camera does not draw power from the connected device.

- ① The camera cannot draw power from Lightning connections or from devices that do not supply power. Select **OFF** before connecting the camera to such devices. The connection may not be available for data transfer or the like when **ON** is selected.
- Regardless of the option selected, the battery will charge while the camera is off.