Multiple Exposures

Create a photograph that combines multiple exposures.



1 Press the **DRIVE/DELETE** button and select **Adv.** > **MULTIPLE EXPOSURE** in the drive-mode menu.



2 Use SHOOTING SETTING > MULTIPLE EXPOSURE CTRL to choose how the exposures are combined.

Option	Description
ADDITIVE	The camera adds the exposures together. You may need to lower exposure compensation depending on the number of shots.
AVERAGE	The camera automatically optimizes exposure for the final picture. The background in series shot without changing the composition will be optimally exposed.
BRIGHT	The camera compares the exposures and chooses only the brightest pixel at each location. Colors may be mixed depending on their brightness and hue.
DARK	The camera compares the exposures and chooses only the darkest pixel at each location. Colors may be mixed depending on their brightness and hue.

3 Take the first shot.